



Step #1

Choose a mounting location on any side of the spa. Position of the Mounting Bracket should be near the top of the spa skirt to allow the tray to clear the spa by approximately 1".

Step #2

Mount the bracket to the spa skirt using the #12 screws provided. Pre-drilling the screw holes is recommended, however, **DO NOT** drill completely through the spa skirt.

Step #3

Insert the tube into the underside of the tray, pushing it in as far as possible.

ITEM	PART#	DESCRIPTION	QTY
A	100689	SPA CADDY BRACKET	1
B	100301	SPA CADDY TRAY	1
C	100438	SPA CADDY POLE	1
D	100801	#12 X 1" MOUNTING SCREW	8