



**1500 Nationale, Lachenaie, Québec, J6W 6M1 Tél: ( 450 ) 964-2218 Fax: ( 450 ) 964-0499**

## **Système d'élastiques**

### **Hors-terre**

-Installer le câble d'acier autour de votre piscine avec le tendeur et le serrer.

-Installer les élastiques selon le modèle de votre piscine en les fixant sur le câble d'acier.

-Installer votre toile par dessus vos élastiques et serrer le tendeur.

### **Creusée**

-Installer le système d'élastiques à l'aide de piquets à l'extérieur des trottoirs.

-Installer votre toile au-dessus de vos élastiques et la retenir avec des tubes d'eau, ou en option avec un ensemble d'élastiques d'étirement.  
( voir catalogue en magasin )

## **Elastic system**

### **Above-ground**

-Install the steel cable around the Pool using the winch, and tie it tightly.

-Install the elastics according to the model of the pool, by fixing them on the steel cable.


-Install the cover over the elastics and tie it using the winch.

### **In-ground**


-Install the elastics by using stakes just outside of the sidewalk.

-Install the cover over the elastics and hold it in place by using water tubes or, in option, use the stretching elastics kit.  
( see in-store catalogue )

**Piscine hors-terre  
Rong / round**



**Above-ground pool  
Ovale / oval**



**Piscine creusée / inground pool  
Toutes formes / all shapes**

