



NEW ABOVE GROUND POOL KIT WALL INSTALLATION ADVISORY

If, for any reason, you need to delay your above ground pool installation, you must take down the pool wall until you can fully complete the installation. You must also take down the wall if you are delaying filling the pool with water for any reason.

Above ground pools are designed to be filled with water, so the water is integral to the pool's stability and structural integrity. Without the correct amount of water supporting the wall, you run the risk of the pool wall collapsing.

If the pool wall collapses and becomes damaged, you are responsible for the replacement cost of the wall. Damage from an empty pool collapsing is not covered by warranty.

The bottom line is never to leave an above ground pool empty and unattended. To protect your above ground pool, you must always ensure the pool is filled to the correct level.