



## **Measuring Your Above Ground Swimming Pool**

**Measure twice, order once!** With our simple measuring guide it is easy to measure your pool, but always remember to double check your measurements for the perfect fit.

### **Round Pool Liners**

If you have a round above ground pool, measure the diameter straight across the center of the pool from a couple of different spots, inside the top of the pool liner wall to inside the top of the opposite wall. Sometimes above ground pools shift slightly (becoming less round in spots), so taking the average of 2 or 3 diameter measurements is the best way to be accurate.

### **Oval Pool Liners**

If your above ground pool is oval, you will want to measure the length from end to end at the center of the pool, and the width in 2 or 3 spots. Then, take the average width from your measurements. Again, measure from one inside wall to the other inside wall for length and width to get the correct measurement.

### **Rectangular Pool Liners**

If your above ground pool is rectangular, measure the length and width and be sure to note what type of corners your pool has. Some rectangular pools have square corners, some pools have diagonal corners and some have rounded corners. If you are ordering a stock rectangular pool liner, those will have with 90 degree (square) corners.

### **Pool Wall**

When you measure the height of your pool wall, measure from outside the pool (not inside the pool), from the bottom rail to just under the top rail to ensure the most accurate pool wall height. Measuring from outside the pool ensures that sand or pool cove on the inside will not throw off your measurement.

Above ground pools typically have 48 inch, 52 inch or 54 inch high walls.



## Comment Mesurer les Piscines Hors Terres

Il faut que vous faites mesurer deux fois pour être sûr! Avec notre guide de mesure simple, c'est plus facile pour obtenir les mesures pour votre piscine. S'il vous plait, souviens toujours de vérifier les mesures pour être sûr que toutes les informations soit correct!

### Les Toiles pour les Piscines Rondes

Si vous avez une piscine hors terre ronde, mesurer le diamètre de la piscine par plusieurs endroits différents; par intérieure de la piscine au mur parallèle. C'est possible que les piscines hors terre bougèrent (ça vient plus ou moins ronds a quelle que endroits), c'est pourquoi prendre quelle que mesures différent serait la meilleure option pour avoir une mesure exacte.

### Les Toiles pour les Piscines Ovale

Si vous avez une piscine hors terre ovale, vous aurez besoin de mesurer la longueur au centre de la piscine dans plusieurs endroits différents, puis prendre la moyenne de ces mesures pour la longueur et aussi la largeur. De plus, mesurer encore par l'intérieur de la piscine pour avoir la mesure le plus exacte.

### Les Toiles pour les Piscines Rectangulaires

Si vous avez une piscine hors terre rectangulaire, mesurer les deux dimensions (longueurs et largeurs). Être sûr de mentionner si vous avez les coins arrondis ou carrée. Si vous commandez une toile pré-créé, il sera une toile avec les coins carrée au 90 degrés.

### La Mur de la Piscine

Quand vous mesurez la hauteur de votre mur de piscine, vous avez besoin de mesurer par l'extérieur de la piscine, par le rail en bas jusqu'à le rail en haute pour obtenir la mesure le plus précise. Nous recommandons de faire les mesures par extérieur pour que la pente des doucins ne dérange pas les mesures.